



measurement competence centre  
[www.artemes.org](http://www.artemes.org)

## **ARTEMES Software**

© 2017 ARTEMES GmbH

# Table of Contents

Foreword	0
<b>Part I Introduction</b>	<b>5</b>
<b>Part II How to start</b>	<b>5</b>
<b>Part III Measurement instrument</b>	<b>6</b>
<b>1 Setup a measurement</b>	<b>7</b>
<b>Input Channels</b>	<b>9</b>
Analogue Channel Setup	9
TEDS	12
Hardware has changed	13
CAN Channels	13
<b>Power Module Setup</b>	<b>13</b>
Grid Type	16
Single Phase	17
2 Phase	18
3 Phase Star	18
3 Phase Delta	20
DC	20
Additional Values	22
UN	23
IN	23
IPE	23
Calc ULL	23
Calc. Third current	24
Save Currents	25
FFT / Harmonics	27
Trigger / Fault recorder	27
Voltage Band Star	28
Voltage band delta	29
Voltage Slope Star	30
Voltage Slope Delta	30
Rapid Voltage Changes	31
Custom Trigger	31
Band	32
Harmonic	33
Frequency band	33
Slope	34
PMU / Phasor Measurement	34
Mathe channels	36
<b>Extra Module Setup</b>	<b>37</b>
<b>Storing the Data</b>	<b>38</b>
<b>2 Online measurements</b>	<b>39</b>
<b>Overview - Online</b>	<b>40</b>
<b>Scope - Online</b>	<b>44</b>
<b>FFT - Online</b>	<b>46</b>
Online FFT with Limits	47

Columns Selection.....	47
PMU - Online .....	49
New Transients .....	50
Config Info .....	51
<b>3 Recording Data .....</b>	<b>51</b>
<b>Part IV Data analysis .....</b>	<b>52</b>
1 Analyze .....	53
2 Info .....	53
3 Charts .....	54
The Zoom Function .....	55
Changing a Graph .....	56
More Graphs on one page .....	60
Math Functions .....	62
Math Functions with Different Power Modules .....	63
4 FFT .....	64
FFT with Limits .....	67
5 Transients .....	68
Transients View .....	68
Changing the Transient View .....	70
6 Events .....	71
7 Alarms .....	72
8 Reports .....	72
<b>Part V The Server Solution .....</b>	<b>73</b>
<b>Part VI Report Engine .....</b>	<b>73</b>
1 Predifined Reports .....	73
<b>Part VII Matlab(TM) routines to load Data .....</b>	<b>75</b>
1 Loading recorded data (reduced storing) .....	75
2 Loading triggered data (full sample storing) .....	76
3 Loading streamed data (full continuous sample storing) .....	76
4 Get the Channel Index .....	77
5 To normalice to a new time axis .....	77
6 Loading the Event List .....	78
<b>Part VIII Installation and System Setup .....</b>	<b>78</b>
1 System Setup of measurement instrument .....	78
2 Installing the Measurement instrument .....	78
3 Installing the Web Server .....	78
4 Channel List File .....	83
<b>Part IX Step by Step Tuturial .....</b>	<b>84</b>

<b>1 Power Measurement .....</b>	<b>84</b>
Low Voltage Grid .....	84
Medium and High Voltage Grid .....	88
Low Voltage Delta (Motor) .....	90
Low Voltage Star with artificial Star point (Motor) .....	91
<b>2 Report: EN50160 .....</b>	<b>93</b>
 <b>Index</b>	 <b>100</b>



# 1 Introduction

**ARTEMES POWER** is a web-based software for data recording and includes some strong toolboxes for calculations in the field of power measurement, power quality, power fault analysis, phasor measurement and power efficiency.

It's currently **version 3**.

The basic architecture contains a windows service task which is the measurement kernel. Due to its operation in the background it obtains its unique stability and performance.


Above this, kernel is the web interface which communicates directly with the web browser using web sockets - the state of the art technology for really quick data communication. With the help of this technology the system is able to transfer even scope data on time to the clients' devices. Client devices can be any browser based instruments such as a computer and notebook, tablet or smartphone.

# 2 How to start

To run the programme you need **NO** additional software. Just start your web browser and type in the IP address of the instrument or data server to which you want to connect to.

Example: 192.168.50.118


You will get a log on screen as the following:




After filling in the user name and password you get the start screen of the instrument or server.

"Force user session takeover" ... in the case that two users with the same name are logging on at the same time you can kill the other session. Otherwise you do not have writing but only reading permission.

Possible start screens:



[Measurement instrument in setup mode](#)



[Measurement instrument in running mode](#)


Name	Status	Type	Location	Action
ARTEMES-001	OK	Server	...	[Stop]
ARTEMES-002	OK	Server	...	[Stop]
ARTEMES-003	OK	Server	...	[Stop]
ARTEMES-004	OK	Server	...	[Stop]
ARTEMES-005	OK	Server	...	[Stop]
ARTEMES-006	OK	Server	...	[Stop]
ARTEMES-007	OK	Server	...	[Stop]
ARTEMES-008	OK	Server	...	[Stop]
ARTEMES-009	OK	Server	...	[Stop]
ARTEMES-010	OK	Server	...	[Stop]

[Server](#)


### 3 Measurement instrument

After logging on to the measurement instrument the home screen appears.

The home screen can be either the setup mode or the measurement mode.




[Setup mode](#)



[Measurement mode](#)

### 3.1 Setup a measurement


In the setup mode the first screen looks the following:



On the left side you see:

**Current setup...** the selected setup - in our example it is "test"

If the list is empty create a new one by using the menu **Setups - > Create new Setup**




Other actions:

**Download** the setup to a local drive

**Rename** a setup

**Reset** changes (reloads the last stored Version)

**Saves** the current settings - same as 

**Delete** setup

Other menu topics:

[Al...](#) to set up the analogue input channels

[Power...](#) to set up power modules

[Extra Module...](#) to define additional modules (groups of measurement channels)

[Analyze...](#) to start data processing - either during setup up or even during the running measurement task



...to start the measurement (without storing)



...to start storing (red blinking button indicates, that storing has already been started)



...???



...system settings

Help...open this help



...log out

### 3.1.1 Input Channels

All means all Input channels-

You can choose from different pages now like:

[Analogue Inputs](#)

CAN Inputs (Option)

Others (if available - depending on hardware)


Name	Range (Prim / Sek)	Sensor	Amplifier	Filter
ai0	564.7 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai1	565.6 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai2	566.3 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai3	10.0 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai4	49.7 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai5	49.7 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai6	988.4 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai7	10.0 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai8	10.0 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai9	10.0 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai10	10.0 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai11	10.0 V / 10.0 V(at ADC 10)	Direct	DIRECT - DIRECT	3 KHz
ai12	1000.0 A / 1000.0 A(at ADC 10)	AM90-001-001030	AM-A-V - LV	10 KHz

#### 3.1.1.1 Analogue Channel Setup

The list of analogue channels shows all analogue input channels - independent from their physical value or size.

Depending on the instrument type this list can be very short (example 4 channels of AM10-CLOG) or very large (example: AM50-128 channel systems)

If the [hardware has changed](#) or the setup comes from a different instrument then wrong channels are indicated in orange.



**Sample rate**...the common sample rate of the analogue channels (can be limited for each channel individually by setting sample rate divider in the channel setup itself)  
 The suggested values are depending on the used hardware (for example 100 Hz for CLOG, 2 MHz for AM10-PA2)

**Scan inputs**...to scan all inputs for the connected sensor (If the connected sensor supports our [TEDS](#) interface it will be detected automatically and the input is set according to the sensor)



...to activate/deactivate the channel



...channel is active and gets stored



...channel is active but not stored (only to show the value or to use in MATH)




...channel is not used



...Color selection with the color tool

Here you can just choose a color for the channel by selecting with the mouse or other pointing



device in use.

**Setup...** to set up the channel just select the line and the properties will be shown on the right side:

### Caption

### Sensor Direct

### Type

### Mode

### Filter

### Range

### Prim

### Sec

### Offset

### ADC Range

Counter

<b>Amplifier Type</b>	1000
<b>Amplifier SN</b>	
<b>Amplifier calib date</b>	1900-01-01
<b>ADC Type</b>	PCI-6013

**caption**...name of channel

**sensor**...select the sensor or the sensor is indicated when a [TEDS](#) is used

**type**...hardware input type (for example ARTEMES AM-A-V, Direct,...)

**Mode**...hardware Setting (for example HV, LV, Lemo, Direct,...)

**Filter**...the used filter (if used), depending on the hardware this field can be empty

**Range**...the maximum range value (ranges depend on the Hardware)

**Prim**...If a transducer is connected to the instrument you can set here the primary value (for example 10 kV).

**Sec**...If a transducer is connected to the instrument you can set here the secondary value (for example 100 V).

**Offset**...If a transducer with offset is connected to the instrument you can set here the offset value.

**ADC Range**...the internal ADC range for fine tuning

**Counter**...if you want to use a analogue channel as a counter then activate this box. Then the channel counts analogue pulses on the input and gives this value as result (application example: energy meter monitoring)

In this case additional setup boxes come up:

Counter
  Falling edge
 Threshold Value 
Factor

**Falling Edge**..when the counter shall grow on falling edge (active) or rising edge (inactive) of the signal

**Threshold Value**...the value of the signal where the counter increases the value

**Factor**... the meter constant (for example 1000 pulses per kWh)

#### 3.1.1.1.1 TEDS

TEDS = Transducer Electronic Data Sheet

Most of the ARTEMES sensors have a TEDS inside. They are automatically recognised after pressing "**SCAN Inputs**".

The sensors are then shown in green with their serial number and the mode turns to the right value.

---

---

---



### 3.1.1.1.2 Hardware has changed

If the hardware changed after the last time the setup had been used or if the setup comes from another instrument then different hardware channels are indicated in orange.

DIRECT	DIRECT	10 V pk
AM-A-V	LV	10.0 (0.
AM-A-V	LV	10.00 (
AM-A-V	LV	10.00 (
AM-A-V	LV	10.00 (
DIRECT	DIRECT	10 V pk
DIRECT	DIRECT	10 V pk

This is also indicated on the top menu bar and the "**Confirm Changes**" button must be pressed.

Setup inputs has changed.

After pressing this button the changes are accepted and the channels turn into black.

### 3.1.1.2 CAN Channels

to be added

## 3.1.2 Power Module Setup

The power module setup starts with the following screen, where you can easily add or remove the power modules.

One power module is like a virtual power meter that can do power measurement, power quality, phasor measurement (option), frequency analysis and fault recording at the same time.

You can define several modules with different wiring schematics and even different frequencies. Input channels can be used more times, so that you can define for example more power modules with the same voltages and different currents for multi-channel power analysis.

**Name**... name of the module as it is seen later on the online screens or in data analysis.

**Choose a grid Type**...to choose the [Grid Type](#) directly

**Sample rate Divider**...If calculation for the power module must not be done for the full recording rate, this value can be set. Example: Raw data recording is 1 MHz, but the power or harmonics are just needed up to 10 kHz, then set the divider to 100. It saves calculation power and memory space.

**Description**...individual text

**Nominal voltage**...the nominal voltage of the system. It is used for the fault recorder, where you can define relative limits to nominal voltage. Also some reports use this value like harmonics analysis.

Normally it is **LE** what means line to earth voltage (phase voltage). For delta applications or when you calculate line values from phase values (calculate ULL) then **LL** is indicated and the nominal line voltage must be defined.

**Nominal Frequency**... the nominal Frequency of the system. This value is also used for relative limit calculations and for setting the flicker filter.

**Frequency Source**...normally the voltage is the source for frequency calculation. In some cases (PWM) the source might be set to current.

**Period count**...the number of periods used for harmonics calculation (default, as defined by IEC 61000-4-7, it is 10)

**Period duration**...the duration for the calculation of period values (normally 1).


**Overlap Factor**...the overlapping of the period values in %.

Example 1: If you want to have half period values then set period duration to 1/2 and overlapping to 0%

Example 2: If you want to have period values which are recalculated each half period then set period duration to 1 and overlapping to 50%

Example 3: If you want to have pure period values then set period duration to 1 and overlapping to 0%

Symmetric components:



**Symetric Components**


Basic Calculation       Enhanced Calculation

**Basic calculation**...enables the calculation according to IEC 61000-4-30 based on 10 period values (or what ever is set up in period count).

**Enhanced calculation**...enables the calculation according to IEC 61400-21 based on period values.

Flicker:

The flicker calculation according to IEC 61000-4-15 can be done by using this toolbox. In addition the current flicker (or flicker emission) can be calculated according to IEC 61400-21.



Flicker       Save Current Flicker

**PST (min)**      **PLT (PST count)**      **Flickerfilter (Hz)**

10      12      Auto

**PST Overlap [%]**      **PLT Overlap (%)**

0      0

**Flicker**...enables the voltage flicker calculation

**PST (min)**...the PST time - normally 10 minutes, but can be changed

**PLT (PST count)**...PLT count - normally 12 PST values

**Flickerfilter**...values

**PST Overlap**...If you want to have a sliding flicker PST value, then define the overlapping factor here. For example 50% means: to calculations of PST happens all 5 minutes for a 10 minute window.

**PLT Overlap**...If you want to have a sliding flicker PLT value, then define the overlapping factor here. For example 50% means: to calculations of PLT happens all 6 PST values for a 12 value window.

**Save current Flicker**...enables the current Flicker calculation (see IEC 61400-21)

Flicker
 Save Current Flicker

---

<b>PST (min)</b>	<b>PLT (PST count)</b>	<b>Flickerfilter (Hz)</b>
<input type="text" value="1"/>	<input type="text" value="12"/>	<input type="text" value="Auto"/>
<b>PST Overlap [%]</b>	<b>PLT Overlap (%)</b>	
<input type="text" value="0"/>	<input type="text" value="0"/>	
<b>Impedanz</b>	<b>Unit</b>	<b>Angle</b>
<input type="text" value="1"/>	<input type="text" value="Ohm"/>	<input type="text" value="30;50;70;85"/>

**Impedance**...the grid impedance where the flicker emission shall be calculated. If the unit is VA then fill in the short circuit power.

**Unit**...Ohm for impedance or VA for short circuit power

**Angle**...the grid angle to be calculated - 30,50,70 or 85 degree. Can also be 4 values at the same time.

Other TABS:

[Choose a grid type](#)

[FFT](#)

[Flicker](#)

[Mathe Channels](#)

[Trigger / Fault recorder](#)

[PMU / Phasor Measurement](#)

### 3.1.2.1 Grid Type

The grid type is the wiring schematic and can be, depending on the individual application, different.

The main types are:

[Single Phase](#)


[2 Phase](#)

[3 Phase Star](#)

[3 Phase Delta](#)


[DC](#)

To modify your schematics to 5-wire (Neutral Line and PE) or Aron (V-Connection) you can individually set [additional Values](#)



### 3.1.2.1.1 Single Phase

The single-phase connection is used for example for equipment testing or single phase loads in distribution panels.



**U L1..** the voltage channel

**I L1..**the current channel


In addition you can also define:

[U N](#)  
[I N](#)  
[I PE](#)

Or you can measure only the voltage by removing the current channel (disable [Save Current](#)).

### 3.1.2.1.2 2 Phase

2-phase systems are used to transfer single-phase energy on HV Lines. Typically railways are using this possibility.



**U L1, 2..** the voltage channels

**I L1, 2..**the current channels


In addition you can also define:

[U N](#)  
[I N](#)  
[I PE](#)

Or you can measure only the voltage by removing the current channel (disable [Save Current](#)).

### 3.1.2.1.3 3 Phase Star

3-phase star systems are the most common connection - also known as 4-wire connection. In combination with the neutral and earth (PE) it is called 5-wire connection.



**U L1, 2, 3..** the voltage channels (phase values connected from line to neutral)  
**I L1, 2, 3..**the current channels

In addition you can also define:


[U N](#)  
[I N](#)  
[I PE](#)

Or you can measure only the voltage by removing the current channel (disable [Save Current](#)).

To measure combined voltage connections in medium and high voltage systems use the [Calc U LL](#) option.

## 3.1.2.1.4 3 Phase Delta

This connection schematic is used, where no neutral is available. Typically this is when an electric motor is connected directly to the power supply.



**U L1, 2, 3..** the voltage channels (line values connected from line to line) UL1 means U12, UL2 = U23, U3 = U31

**I L1, 2, 3..**the current channels

In addition you can also define:

**U N** (if it makes sense)

**I N** (if it makes sense)

**I PE** (if it makes sense)

Or you can measure only the voltage by removing the current channel (disable [Save Current](#)).

Note: the **nominal voltage** is set to line values as well !


To save a current sensor you can use the option [Calc. third current](#) (ARON, V-connection).

## 3.1.2.1.5 DC

For real DC applications an own DC module is available.

The main difference in calculation is that there is no frequency available and the calculation is done only time based.





**U L1**.. the voltage channel


**I L1**..the current channel

Or you can measure only the voltage by removing the current channel (disable [Save Current](#)).

On the parameters' side (General TAB) there is also a change and you can define only limited parameters now:

**Nominal voltage**...the nominal voltage of the system. It is used for the fault recorder, where you can define relative limits to nominal voltage. Also some reports use this value like harmonics analysis.

**Sample rate divider**...If the calculation for the power module does not have to be done for the full recording rate, this value can be set. Example: Raw data recording is 1 MHz, but the power is just needed up to 10 kHz, then set the divider to 100. It saves calculation power and memory space.



### 3.1.2.1.6 Additional Values

The following additional values can be set - depending on the wiring schematic and number of real input channels:

[UN](#)  
[IN](#)  
[IPE](#)

[Calc ULL](#)

[Calc third current](#)

[Save Currents](#)

## Choose a grid type

3 Phase Star

- Calc. ULL  
 Calc. third current  
 I N

- Calc Currents  
 U N  
 I PE

U L1

ai0

I L1

ai4

U N

ai3

U L2

ai1

I L2

ai5

I N

ai7

U L3

ai2

I L3

ai6

I PE

ai8



## 3.1.2.1.6.1 U N

Use this if you also want to measure the voltage between neutral N and protected earth PE.

U N

ai3

## 3.1.2.1.6.2 I N

Use this if you also want to measure the current on the neutral line.

I N

ai7

## 3.1.2.1.6.3 I PE

Use this if you also want to measure the current on the protected earth.

I PE

ai12

## 3.1.2.1.6.4 Calc ULL

In some cases beside the phase values also the line values shall be evaluated.

**Example:** measurement in a medium or high voltage grid  
The VTs (voltage transducers) are connected between line and earth.

If you want to see the U<sub>LE</sub> (Phase values) for the earth fault detection and the U<sub>LL</sub> (Line values) for the power quality (U<sub>c</sub>) use this option.

Harmonics and Flicker can then be calculated for U<sub>LE</sub> and U<sub>LL</sub>.

#### Choose a grid type

3 Phase Star

Calc. ULL

Calc. third current

I N

Calc Currents

U N

I PE

U L1

ai0

I L1

ai4

U L2

...

I L2

...

**Attention:** By using this option the nominal Voltage switches from U<sub>LE</sub> to U<sub>LL</sub>! (left side, third line in the following picture)

ARTEMES Setups AI Power

module Add Powermodule

General Choose a grid type FFT Mathe channel

Name module Ch

Description

Nominal Voltage LL [V] 398 No

**Note:** This option is not available for delta and single-phase measurements.

#### 3.1.2.1.6.5 Calc. Third current

If you want to save the third current connection you can choose this option (Also used as **ARON** or **V-connection**).

The third current is then calculated by  $i_3 = -i_1 - i_2$ .

Attention: It works only when there is no neutral line connected!

Attention: Don't use for PWM applications - there the capacitive current is too high and influences the result.

module
Add Powermodule

General
Choose a grid type
FFT
Mathe channels
Trigger

**Choose a grid type**

3 Phase Star

Calc. ULL

Calc. third current

I N

Calc Currents

U N

I PE

**U L1**

ai0

**U L2**

ai1

**U L3**



ai2

**I L1**

ai4

**I L2**

ai5

#### 3.1.2.1.6.6 Save Currents

When you remove the currents only voltages are stored.

This will be used when you want to evaluate only voltages as for pure power quality measurements (for example EN 501060 defines only voltage limits).

module [Add Powermodule](#)

General **Choose a grid type** FFT Mathe channels Trigger

**Choose a grid type**



3 Phase Star

Calc. ULL  Calc Currents  
 U N

**U L1**  
ai0  ■

**U L2**  
ai1  ■

**U L3**  
ai2  ■



### 3.1.2.2 FFT / Harmonics

To calculate the FFT values according to IEC 61000-4-7 enable this part of the ARTEMES power tool box.

The screenshot shows the ARTEMES software interface with the 'Power' module selected. The 'FFT' tab is active, displaying the following configuration options:

- FFT Count:** Input field with value 50.
- Sidebands Count:** Input field with value 1.
- Interharm. Sidebands Count:** Input field with value 3.
- THD:** Checked checkbox.
- Interharmonics:** Unchecked checkbox.
- Calc. Higher Harmonics:** Unchecked checkbox.
- Smoothing Filter:** Unchecked checkbox.

**FFT Count...**the number of harmonics to be calculated (default 50)

**Sidebands Count...**the number of pins to be added to the exact pin. For example when you have 10 periods calculation and 50 Hz fundamental frequency you get  $50/10 = 5$  Hz values. 1 sideband means the 50 Hz component is the RMS value of 45, 50 and 55 Hz (default = 1).

**Interharm Sidebands Count...**The number of pins used for interharmonics calculation. If this value is 3, then there are used for example 60, 65, 70, **75 Hz** (interharmonics nominal value), 80, 85 and 90 Hz

**THD...**if THD shall be calculated. The value sets the highest harmonic to be used - default is 40 as defined in IEC 61000-4-7.

**Interharmonics...**enables the calculation of interharmonics.

**Calc higher Harmonics...**enables the 200Hz blocks from 2kHz to 9 kHz (according to IEC 61000-4-30). The highest values will be limited by the real bandwidth and sample rate of the instrument.

**Clac Highest Harmonics...**enables the 2kHz blocks up to 150 kHz (according to IEC 61000-4-30). The highest Values will be limited by the real bandwidth and sample rate of the instrument.

**Smoothing Filter...**enables the smoothing filter as described in IEC 61000-4-7

### 3.1.2.3 Trigger / Fault recorder

The ARTEMES power toolbox also includes a very complete fault recorder library.

Beside the storing of raw data (power fault recorder = PFR) during seconds also period values can be stored over minutes. And this is done by a disturbance fault recorder (DFR).

The different predefined trigger modes are:

[Voltage band Star](#)  
[Voltage band delta](#)  
[Voltage Slope Star](#)  
[Voltage Slope Delta](#)  
[Rapid voltage changes](#)

Custom Trigger can be defines [more complex](#)

**Max storage Time**...the maximum length of a triggered record in ms

### 3.1.2.3.1 Voltage Band Star

Typically used for triggers according to standards like EN50160, where you want to see if the band is left or not. Star triggers are used in low voltage grids mainly.

**Voltage Star**...enable to activate the trigger

**Relative**...if enabled the following limit values are to fill in in % of the nominal voltage. If this is deactivated then fill in Volts.



**Max 110%**...the start value for the upper limit

**Max 108%**...the end value for the upper limit

**Min 90%**...the start value for the lower limit

**Min 92%**...the stop value for the lower limit

**Pretime (ms)**...stored time before the trigger starts

**Posttime (ms)**...stored time after the trigger ends

**Holdofftime (ms)**...time to suppress retriggering after a trigger (for example earth faults should be suppressed a little while)

**Posttime ext.**...if the post time shall be extended when the trigger comes up again. In this case the post time starts counting again after the end of the new trigger.

**Flagging**...if the data shall be flagged according to IEC 61000-4-30. If this parameter is set, then all calculated data during this time are marked (flagged) and can be removed for later evaluations for example EN50160.

### 3.1.2.3.2 Voltage band delta

Typically used for Triggers according to standards like EN50160, where you want to see if the band is left or not. Delta Triggers are used in Medium and High voltage grids mainly.

Active  
Voltageband Delta (Active) ▾  Separate Phases

Max. [%] <input type="text" value="110"/>	Max. [%] <input type="text" value="108"/>	Pretime [ms] <input type="text" value="1000"/>	Holdofftime [ms] <input type="text" value="0"/>	Flagging <input type="checkbox"/>	Relative <input checked="" type="checkbox"/>
Min. [%] <input type="text" value="90"/>	Min. [%] <input type="text" value="92"/>	Posttime [ms] <input type="text" value="3000"/>	Posttime ext. <input type="checkbox"/>		

**Voltage Delta**...enable to activate the trigger

**Relative**...If enabled the following limit values have be filled in - in % of the nominal voltage. If this is deactivated then fill in Volts.

**Max 110%**...the start value for the upper limit

**Max 108%**...the end value for the upper limit

**Min 90%**...the start value for the lower limit

**Min 92%**...the stop value for the lower limit

**Pretime (ms)**...Stored time before the trigger starts

**Posttime (ms)**...Stored time after the trigger ends

**Holdofftime (ms)**...time to suppress retriggering after a trigger (for example earth faults should be suppressed a little while)

**Posttime ext.**...if the post time shall be extended when the trigger comes up again. In this case the post time starts counting again after the end of the new trigger.

**Flagging**...if the data shall be flagged according to IEC 61000-4-30. If this parameter is set, then all calculated data during this time are marked (flagged) and can be removed for later evaluations for example EN50160.

## 3.1.2.3.3 Voltage Slope Star

Typically used for triggers where you want to see if there is a jump from one period value to the next.

Active  
 Voltageslope Star (Active) ▾  Separate Phases

<b>Max. Slope[%]</b> <input type="text" value="10"/>	<b>Pretime [ms]</b> <input type="text" value="1000"/>	<b>Holdofftime [ms]</b> <input type="text" value="0"/>	<b>Flagging</b> <input type="checkbox"/>	<b>Relative</b> <input checked="" type="checkbox"/>
<b>Min. Slope[%]</b> <input type="text" value="5"/>	<b>Posttime [ms]</b> <input type="text" value="3000"/>	<b>Posttime ext.</b> <input type="text"/>		

**Voltage Slope Star**...enable to activate the trigger

**Relative**...If enabled the following limit values have to be filled in - in % of the nominal voltage. If this is deactivated then fill in Volts.

**Max Slope**...the limit value for positive changes between two period values

**Min Slope**...the limit value for negative changes between two period values

**Pretime (ms)**...stored time before the trigger

**Posttime (ms)**...stored time after the trigger

**Holdofftime (ms)**...time to suppress retriggering after a trigger (for example earth faults should be suppressed a little while)

**Posttime ext.**...if the post time shall be extended when the trigger comes up again. In this case the post time starts counting again after the end of the new trigger.

**Flagging**...if the data shall be flagged according to IEC 61000-4-30. If this parameter is set, then all calculated data during this time are marked (flagged) and can be removed for later evaluations for example EN50160.

## 3.1.2.3.4 Voltage Slope Delta

Typically used for triggers, where you want to see if there is a jump from one period value to the next.

Active  
 Voltageslope Delta (Active) ▾  Separate Phases

<b>Max. Slope[%]</b> <input type="text" value="10"/>	<b>Pretime [ms]</b> <input type="text" value="1000"/>	<b>Holdofftime [ms]</b> <input type="text" value="0"/>	<b>Flagging</b> <input type="checkbox"/>	<b>Relative</b> <input checked="" type="checkbox"/>
<b>Min. Slope[%]</b> <input type="text" value="5"/>	<b>Posttime [ms]</b> <input type="text" value="3000"/>	<b>Posttime ext.</b> <input type="text"/>		

**Voltage Slope Delta**...enable to activate the trigger

**Relative**...If enabled the following limit values have to be filled in - in % of the nominal voltage. If this is deactivated then fill in Volts.

**Max Slope**...the limit value for positive changes between two period values

**Min Slope**...the limit value for negative changes between two period values

**Pretime (ms)**...Stored time before the trigger

**Posttime (ms)**...Stored time after the trigger

**Holdofftime (ms)**...time to suppress retriggering after a trigger (for example earth faults should be suppressed a little while)

**Posttime ext.**...if the post time shall be extended when the trigger comes up again. In this case the post time starts counting again after the end of the new trigger.

**Flagging**...if the data shall be flagged according to IEC 61000-4-30. If this parameter is set, then all calculated data during this time are marked (flagged) and can be removed for later evaluations for example EN50160.

### 3.1.2.3.5 Rapid Voltage Changes

Geben Sie hier den Text ein.

Active

Rapid voltage changes (Acti v

Separate Phases

**TDC**

100

**Limit tdc**

1

**Limit**

0.5

**Max Limit**

6

### 3.1.2.3.6 Custom Trigger

Custom Trigger can be defined very individual



...to add a Trigger



...to remove a Trigger

**Active...**to activate the Trigger

**Caption...**name of the Trigger

**Triggertype:** there a 4 different types of Trigger

[Band](#)

[Harmonic](#)

[Frequency band](#)

[Slope](#)

Common settings for all:

**channel...**the used channel of the Trigger

**Pretime (ms)**...stored time before the trigger starts

**Posttime (ms)**...stored time after the trigger ends

**Holdofftime (ms)**...time to suppress retriggering after a trigger (for example earth faults should be suppressed a little while)

**Posttime ext.**...if the post time shall be extended when the trigger comes up again. In this case the post time starts counting again after the end of the new trigger.

**Flagging**...if the data shall be flagged according to IEC 61000-4-30. If this parameter is set, then all calculated data during this time are marked (flagged) and can be removed for later evaluations for example EN50160.

#### 3.1.2.3.6.1 Band

**band type**...enter or leave the band

**startmax**...the start value for the upper limit

**stopmax**...the end value for the upper limit

**startmin**...the start value for the lower limit

**stopmin**...the stop value for the lower limit

### 3.1.2.3.6.2 Harmonic

Harmonic band Trigger

This Trigger is similar to the band Trigger, but can use a Harmonic

<b>Band typ</b>	<b>Harmonic</b>	<b>startmax</b>	<b>stopmax</b>
Verlas: ▾	1	1	0.98
		<b>startmin</b>	<b>stopmin</b>
		0	0

**band type**...enter or leave the harmonic band

**harmonic**...the order of Harmonic

**startmax**...the start value for the upper limit

**stopmax**...the end value for the upper limit

**startmin**...the start value for the lower limit

**stopmin**...the stop value for the lower limit

### 3.1.2.3.6.3 Frequency band

Frequency band Trigger

This Trigger is similar to the band Trigger, but can use the rms value of a Frequency range

In this example the range from 49 to 51 Hz will be used and start a triggered record when the value is larger then 1

<b>Band typ</b>	<b>Max F [Hz]</b>	<b>startmax</b>	<b>stopmax</b>
Verlas: ▾	51	1	0.98
	<b>Min F [Hz]</b>	<b>startmin</b>	<b>stopmin</b>
	49	0	0

**band type**...enter or leave the harmonic band

**Max F (Hz)**...the lower Frequency value

**Min F (Hz)**...the lower Frequency value

**startmax**...the start value for the upper limit

**stopmax**...the end value for the upper limit

**startmin**...the start value for the lower limit

**stopmin**...the stop value for the lower limit

#### 3.1.2.3.6.4 Slope

<b>Max. Slope</b>	<b>Min. Slope</b>
<input type="text" value="0"/>	<input type="text" value="0"/>

---

**Max slope**...the upper value for the slope trigger

**Min slope**...the lower value for the slope trigger

#### 3.1.2.4 PMU / Phasor Measurement

The PMU (phasor measurement unit) is an extra Option.

If it is activated and installed you can easily enable it in the power setup page.

Enable PMU

---

**PMU Identifier**...identifier as defined for the IEEE PMU protocol.

**PMU Name**...individual name

**PMU Header**...additional note

**Reporting Rate**...select 10 or 25 Hz

Enable PMU

---

**PMU Identifier**

0

**PMU Name**

**PMU Header**

**Reporting Rate**

FFT

Additionally to voltage and current phasors the ARTEMES PMU can also send power quality parameters.

For this you must enable **FFT**.

On the right side you can then add the **harmonics** you want to get on the PMU server.

By default the voltage FFT is sent, If you want to get current values as well enable this **FFT current** option.

Also the flicker is available as output 5 of the flicker meter.

Enable PMU

---

**PMU Identifier**

**PMU Name**

**PMU Header**

**Reporting Rate**

FFT  
 FFT Current

**Harmonics**

<input type="text" value="3"/>	<input type="text" value="-"/>
<input type="text" value="5"/>	<input type="text" value="-"/>
<input type="text" value="7"/>	<input type="text" value="-"/>

### 3.1.2.5 Mathe channels

Mathe channels can be assigned to a power module and are used to add other measured parameters or mathematic channels.

Example: a wind speed for wind turbine tests.

Later these channels can be used in data processing and found in the same data set.

module [Add Powermodule](#)

General Choose a grid type FFT **Mathe channels** Trigger

**Mathe channels**

Active	Physical channel	Logical channel
<input type="button" value="+Add channel"/>		

**+Add channel**...adds a channel to the power module

**Physical channel**...the AI channel, or CAN channel or other physical source defined in the channel setup.

**Save interval**...the storing interval of this channel



Active	Physical channel	Logical channel	
<input checked="" type="checkbox"/>	ai0	CUSTOM7	100


+Add channel

You can add as many channels as you need.

If you want to group channels without a power module simply use the "[extra module](#)" function.

### 3.1.3 Extra Module Setup

To Add an Extra Module click Extra Module and the Add Module



What is an extra module?

An extra module is a module to make groups of channels. These channels can then be found under the module name in data analysis.

For Example: You have two test benches with two same channels like temperature and humidity. Then you define one extra module as test bench1 and assign two channels: temperature an humidity.

Then you define one extra module as test bench2 and assign two channels: temperature an humidity.

In post processing you prepare the one chart for temperature and humidity and can then choose between bench 1 and bench 2.

These modules can also be on different instruments when you store the data on the server.

Also the channels could be on different instruments - the extra module name must just be the same one (for post processing in Matlab(r)/Octave).

**Name**...name of the module as it will be found in [Data Analysis](#)

**Description**...individual text

Channels:

**Add channel** ... to add a channel. The channels must be defined previously in the [AI channel setup](#)

**Add Module**...to add extra modules

**Delete Module**...to remove the module


The next screen shot shows two added channels form different sources (CAN and Analogue Channel) and with different storing intervals.

Custom Trigger:

with the help of this function yo can add Triggers to extra modules

the settings are the same as for [power Triggers](#)

### 3.1.4 Storing the Data

To Store the Data you need to push the Icon  on the menu bar.

But before you need to define what shall be stored and how.

In general the system uses two different groups of data: "samples" and "reduced" data

"**Samples**" means full samples as chosen in the AI setup - for example 20kHz

"**Reduced**" means average data for example 10 minutes

Each data set can be stored "always" or "on Trigger"

"**Always**" means full streaming mode where all data are stored leakless as slonas you do not

press stop



"**On Trigger**" means data are stored when a Trigger condition happens.

**Storage of Channels**

---

Off
  Always
  On trigger
 **store all samples**

Off
  Always
  On trigger
 **store reduced data**
 global store interval (s)


In addition the storing interval can be set individual or global by selecting the box "**global storing interval**" and setting a value in (s)


The channels can be defined by selecting the checkboxes for Samples or Reduced.


If the Storing interval is not global each parameter has an own row for the individual "**save interval**" (s).

<input type="checkbox"/>	<input type="checkbox"/> Samples	<input type="checkbox"/> Reduced	Type	Module	Name	Unit	<input type="checkbox"/> Save Inte	A
<input type="checkbox"/>	<input checked="" type="checkbox"/>		Synchron	input channel	ai0	-		
<input type="checkbox"/>	<input checked="" type="checkbox"/>		Synchron	input channel	ai1	-		
<input type="checkbox"/>	<input checked="" type="checkbox"/>		Synchron	input channel	ai2	-		
<input type="checkbox"/>	<input checked="" type="checkbox"/>		Synchron	input channel	ai4	-		
<input type="checkbox"/>	<input checked="" type="checkbox"/>		Synchron	input channel	ai5	-		
<input type="checkbox"/>	<input checked="" type="checkbox"/>		Synchron	input channel	ai6	-		
<input type="checkbox"/>			Synchron	input channel	ai12	-		
<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Asynchron	module	Frequency	Hz	<input type="checkbox"/>	1
<input type="checkbox"/>		<input checked="" type="checkbox"/>	Asynchron	module	U_RMS_L1	V	<input type="checkbox"/>	1
<input type="checkbox"/>			Synchron	module	U_L1	V	<input type="checkbox"/>	
<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Asynchron	module	U_RMS_L2	V	<input type="checkbox"/>	1
<input type="checkbox"/>			Synchron	module	U_L2	V	<input type="checkbox"/>	
<input type="checkbox"/>		<input checked="" type="checkbox"/>	Asynchron	module	U_RMS_L3	V	<input type="checkbox"/>	1
<input type="checkbox"/>			Synchron	module	U_L3	V	<input type="checkbox"/>	


## 3.2 Online measurements

Pressing  turns the instrument into the viewing mode.

Pressing  start the [recording mode](#) of the instrument.

Pressing  stops the instrument and returns into the [set up](#) mode.

The following screen shows the default measuring screen. To return to this screen press the ARTEMES logo on top left.



The different measurement screens can be accessed with the main menu and are:

[Overview - Online](#) (ARTEMES logo)

[Scope - Online](#)

[FFT - Online](#)

[PMU - Online](#)

[Config Info](#)

[Analyze](#)

### 3.2.1 Overview - Online

The measurement overview consists of several instruments:  
It can be different depending on the connection schema.

**The selector:**

It lets you choose which power module shall be shown and also indicates the basic power values:

Select Powermodule


House

Frequency	50.031 [Hz]
P Total	628.213 W
Q Total	509.459 VAR
S Total	826.337 VA
PF	0.760
Unbalance U	0.238 %
Unbalance I	0.000 %

**The vector scope:**

It shows the vectors of voltage and current.

With the slider bar you can choose the harmonic order ...



...to export the screen in different formats, as vector graph or as image.

#### Details:

shows phase values


## Details

Caption	Phase 1	Phase 2	Phase 3
U RMS LE	230.124 [V]	228.858 [V]	228.403 [V]
Phi I	44.13 °	39.99 °	25.02 °
Phi U	0.00 °	119.82 °	-119.97 °
I RMS LE	2.572 A	0.531 A	0.925 A
P	374.638 W	90.068 W	175.966 W
Q	367.054 VAr	76.069 VAr	79.106 VAr
S	530.504 VA	118.394 VA	195.254 VA
PF	0.706	0.761	0.901
PST LE	0.299	0.234	0.467
PLT LE	0.668	0.576	0.698
U THD LE	2.535 %	2.173 %	2.545 %

### Recorder:

Online recorder view for voltage, current and power. By clicking on the legend values you can deactivate the view of them.


Using the mouse pointer on the diagram shows you the values.



### 3.2.2 Scope - Online

The scope function is an online function which gives the real curve of the actual voltages and currents. Depending on the speed of the connection the update rate may vary, but the view is always as complete and as actual as possible. The number of points depends on the resolution of the screen.

To set up the scope just activate the channels you want to see and press **start**.



The screenshot shows a control panel for the scope. At the top, there are two buttons: 'Start' (highlighted in green) and 'Stop'. Below these are three input fields with labels: 'Triggerlevel' with the value '50', 'Time [ms]' with the value '20', and 'Pretime' with the value '0'.

**Right**...to use the right axis - for example voltages use the left axis and currents could use the right one for a better scaling.

**Triggerlevel**...the level of triggering the first value - here 10V for UL1

**Time (ms)**... the time window to show on the screen...typically 20ms for one period

**Max**...upper value of the scale of the axis (left or right). If empty the AUTO is used.

**Min**...lower value of the scale of the axis (left or right). If empty the AUTO is used.


**Reload**...to reload the scope for changing parameters

**Stop**...to stop the scope



...to export the screen in different formats, as vector graph or as image.






a very unique function is also the live FFT view on the bottom of the Scope

by selecting a larger Time window (here:200ms) and a large number of FFT Points (here 2048) you can already get a very precise FFT of the input signal

In addition the FFT Filters can be chosen from the following list:


- Hanning
- Haming
- Rectangular
- Lanczos
- Triangular
- Gauss
- Cosine
- Blackmann
- Bartlett
- Bartlettthann



### 3.2.3 FFT - Online

To show the harmonics (FFT) choose this page.

Depending on the wiring schematic you will see phase voltages (UL), line voltage (ULL) and currents.





...to export the screen in different formats, as vector graph or as image.

**Type**..choose from Harmonics, Interharmonics, Higher Harmonics 2-9 kHz or Highest Harmonics 8 to 150 kHz (available only when sampling rate is high enough and function is enabled in FFT setup)


**Abs/Rel**..To choose if the Values are shown absolute (V, A) or relative to the fundamental (%)

[Online FFT with Limits](#)...to show online the limits of e.g. IEC 61000-2-4 or EN 50160

[Columns selection](#)...to select which column of data shall be shown

### 3.2.3.1 Online FFT with Limits


To show the online FFT limits select them from the list given in the pull down menu "limits".




### 3.2.3.2 Columns Selection

On bottom of the page there is a graphical interpretation and on the bottom is a numeric view of the data.

Selecting "column selection" on top of the graphical view enables the columns list on the right side of the numeric view. There you can choose different values to be shown online just by enabling the appropriate parameter.




The possible values are shown in the list:



### 3.2.4 PMU - Online

The phasor measurement option PMU shows the phasors of voltage and current in a vector scope. The rotation indicates whether the frequency is faster or lower than the nominal frequency.

This view is part of the PMU option and needs to be licensed separately. It also requires the PMU hardware option from ARTEMES.



This sign indicates the strength of the GPS signal.




...to export the screen in different formats, as vector graph or as image.

### 3.2.5 New Transients

This page shows new Transients automatically in the measurement mode.

For the settings please see section [Transients in data analysis](#)




### 3.2.6 Config Info

This view shows the setup information as defined in the set up.

The values are the same as in the set up and are only for indication, not to be changed during the running measurement.

For detailed information on the values see the [setup](#) section of this manual




## 3.3 Recording Data

To start recording the data press the record button




This button shall then turn into red and blink in one-second intervals.

The instruments are the same as described in the "[Online measurements](#)" section.

To stop the recording and return to [setup](#) mode press 

The recorded data are shown in the list [Analyze](#).

## 4 Data analysis

The menu item analyze  on the instrument or server brings up a list with all recorded measurements.

Starttime ▾	Endtime ◊	Device ◊	Title ◊	Location ◊	Comment ◊
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
25.04.16, 14:02 ▶	06.05.16, 10:55	AM50	test		
22.04.16, 10:06 ▶	22.04.16, 10:08	AM50	trigger_test	lab	
22.04.16, 09:40 ▶	22.04.16, 09:40	AM50	test_georg	lab	
22.04.16, 09:16 ▶	22.04.16, 09:23	AM50	test_georg	lab	
13.04.16, 17:29 ▶		AM50	asdfsdf		
13.04.16, 17:26 ▶	13.04.16, 17:27	AM50	testrecord	lab	
07.04.16, 11:52 ▶		AM50-2	demo		
07.04.16, 11:51 ▶	07.04.16, 11:52	AM50-2			
07.04.16, 11:51 ▶	07.04.16, 11:51	AM50-2			
31.03.16, 13:21 ▶		AM50-2	test 16		

10 25 50 100

**Starttime**...Clicking on the date opens the selected measurement for further analysis.  
 - ... deletes the measurement

By using the **up and down** arrows beside the titles you can **sort** the measurements.

By using the fields **above the rows** you can **filter** the data.

Example: the following list was filtered by device "AM50" and title "Trigger".

Starttime ▾	Endtime ◊	Device ◊	Title ◊	Location ◊	Comment ◊
<input type="text"/>	<input type="text"/>	<input type="text" value="AM50"/>	<input type="text" value="trigger"/>	<input type="text"/>	<input type="text"/>
22.04.16, 10:06 ▶	22.04.16, 10:08	AM50	trigger_test	lab	

10 25 50 100



**Clear sorting**... resets the sorting criteria

**Clear filter**...deletes the filter

**Reload**..refreshes the list

After opening a measurement the menu changes and you have the following entries:

[Analyze](#)

[Info](#)

[Charts](#)

[FFT](#)

[Transients](#)

[Events](#)

[Alarms](#)

[Reports](#)

## 4.1 Analyze

With this button you return to the [list of measurements](#).

## 4.2 Info


This page gives a quick overview on the recorded data, the power modules and the number of events, transients and alarms.

The Infos like measurementtitle, Location and comment can be changed or set.



With  the values are stored.

With "**Export**" you can download the complete data set to your local drive - either in "CSV" or "RAW Data" format.




## 4.3 Charts

Charts are the most used post-processing part.

Any data channel can be chosen and shown as timegraph.


Also data from different modules can be [compared](#) or simple [math](#) can be made with more channels.

To load a predefined graph just choose **start** and **endtime**, the **module** and the **view**, which gives a list of already defined graph sets.




In this example the selected **view** is "P total".

Then press **reload** and the graph will be shown on the screen.



Now you can **set cursors**, export the data with the **export** button (direct CSV export) or the button for different export formats.

**Channel names**...click into the legend to show/hide any channel



Further functions are:

[Zoom](#)

[Changing a Graph](#)

[More Graphs on one page](#)


[Math Functions](#)

[Math Functions with different power modules](#)


### 4.3.1 The Zoom Function

To Zoom just use the mouse and click in the graph window, hold the mouse button and open a rectangular window, then release the button.

The Zoom Menu appears to shift, reset or unzoom



The next window shows a zoomed graph.



### 4.3.2 Changing a Graph

Once the graph is loaded you get an **edit** button on the right side of the view selector.

Click on it and you get the following page:

**close**...to close this page and return to the graph

**add**...to add a new view

**reset**...to reload the previously stored version

**save**...to save the setting

**clone**...to duplicate a graph

**download**...to download the settings

**delete**...to delete the graph

The screenshot shows the ARTEMES software interface for configuring a graph. The main configuration area includes the following sections:

- Name:** P Total
- TransientView:**
- Show Legend:**
- Layout:** Horizontal
- align:** Center
- Vertical Align:** Bottom
- Border width:** 2
- Channel info:**
- X axis Grid Line width:** 1
- Chart height:** 600

**Axes:**

Title	top	height	Height type	Log	minorticks	Min.	Max.
P [W]	0	100	Percentage	<input type="checkbox"/>	0.1		

**Channels:**

Visible	Channel name	Axis	Type	Factor	Aggregation	Channel	Unit
<input checked="" type="checkbox"/>	P	P [W]	Reduced	Factor	avg	P	

The general settings of the graph are:


**Name**...the name of the view

**Transient View**...to use this view also for transients

**Show Legend**...to show the legend of data


**Layout**...the direction of the legend

Layout




**align**...the horizontal align of the legend

align



**Vertical align**...the vertical align of the legend



**Border width**...the width of the border

**X axis Grid line width**...width of the grid

**chart height**...height of the total graph

Axis settings:

Each graph can have more axis.


Each axis has its own height and start position

using the **auto arrange** calculates the height and position automatically.

**Title**...name of axis

**top**...position of then top of the axis (top is 0)

**height**...height of the axis



**height type**...percent or pixel

**log**...logarithmic scaling or not

**min**...lower value or AUTO

**max**...upper value or AUTO

**add axis**...to add an axis

-...to delete an axis

Channel settings:

several channels can be displayed on the graph.

each channel is assign to an axis.

**visible**...to show or hide a channel

**channel name**...name of the channel to be shown

**axis**...in which axis the channel shall be shown

**type**...Data channel or [math](#) channel or raw channel (see [transients view](#) or to show full sample data)

**factor**...a multiplication factor to the value

**aggregatioon**...min/max/or average value of the data

**channel**...the channel from the [channel list file](#)

**Unit**...the Unit of the channel

**add channel**...to add a channel

-...to delete a channel

ARTEMES POWER

hausdemo.artemes.org/#analyze

ARTEMES Extra modules Analyze Info Charts FFT Transients 0 Events 0 Alarms 0 Reports 0 Help

Close Add Reset Save Clone Download Upload Delete

Name: P Total

TransientView:

Show Legend:  Layout: Horizontal

align: Center Vertical Align: Bottom

Border width: 2 Channel info:  X axis Grid Line width: 1 Chart height: 600

Axes

Title	top	height	Height type	Log	minorticks	Min.	Max.
P [W]	0	100	Percentage	<input type="checkbox"/>	0.1		

add axis Auto arrange

Channels

Visible	Channel name	Axis	Type	Factor	Aggregation	Channel	Unit
<input checked="" type="checkbox"/>	P	P [W]	Reduced	Factor	avg	P	
<input checked="" type="checkbox"/>	Q	P [W]	Reduced	1	avg	Q	

Add channel

124.0 GB 27 % available disk space A product of ARTEMES GmbH 2017. All rights reserved.

In our example a second channel Q is added to the Power channel P  
The color is selected as blue.

After saving, closing and reloading the set up the graph is shown as below:



### 4.3.3 More Graphs on one page

To show more graphs simply **add** a chart axis - here it is called "Q".  
 Press **Auto arrange** for setting the top and height values.  
 Then assign the second channel Q to the axis "Q".



The screenshot shows the ARTEMES software interface with the configuration panel for a chart. The panel is divided into several sections:

- Name:** P Total
- Transient/View:**
- Show Legend:**
- Layout:** Horizontal
- align:** Center
- Vertical Align:** Bottom
- Border width:** 2
- Channel Info:**
- X axis Grid Line width:** 1
- Chart height:** 600

**Axes:**

Title	top	height	Height type	Log	minorticks	Min.	Max.
P [W]	0	50	Percentage	<input type="checkbox"/>	0.1		
Q	50	50	Percentage	<input type="checkbox"/>			

**Channels:**

Visible	Channel name	Axis	Type	Factor	Aggregation	Channel	Unit
<input checked="" type="checkbox"/>	P	P [W]	Reduced	Factor	avg	P	
<input checked="" type="checkbox"/>	Q	Q	Reduced	1	avg	Q	

**Save, close and reload** the graph.  
The result will look like the following screen:



#### 4.3.4 Math Functions

In this example we have 2 power channels and we want to add a channel which shows the difference of these 2 channels.

- P\_L1 and P\_L2 must be created first.
- Then create an other channel. The type is math.
- Then choose the math function "sum".
- Assign the first channel P\_L1 with factor "1".
- Click "+" and assign a new channel P\_L2 with factor "-1". The name is "P 1 and 2".

Channels									
Visible	Channel name	Axis	Typ	Factor	Aggregation	Channel	Einheit		
<input checked="" type="checkbox"/>	P_L1	P [W]	Dater	1	avg	P_L1	W		-
<input checked="" type="checkbox"/>	P_L2	P [W]	Dater	1	avg	P_L2	W		-
<input checked="" type="checkbox"/>	P 1 and 2	P [W]	Math	Summe	1	P_L1	W	-	-
					-1	P_L2	W	-	+

Add channel

Save, close and reload the graph. The result will look like the following screen:



### 4.3.5 Math Functions with Different Power Modules

If you have defined math channels you can even use different power modules.


Just choose the modules after loading the graph.

Measurementtitle: wpt

Starttime: 13.04.2016 09:41 | Endtime: 15.04.2016 09:41 | Module: House | View: P Total | Edit

Visible	Channel name	Axis	Typ	Module	Channel	Einheit
<input checked="" type="checkbox"/>	P_L1	P [W]	Daten		P_L1	W
<input checked="" type="checkbox"/>	P_L2	P [W]	Daten		P_L2	W
<input checked="" type="checkbox"/>	P 1 and 2	P 12	Math	Summe	House House	W W

In this example the module "House" of the P\_L2 was changed to "P" from the module PV. The result shows the power from the module "house" minus the "PV" system.



## 4.4 FFT


The evaluation of the harmonics (FFT) can be done in three ways.

- 1) Bar graph...as described on this page
- 2) [Time graph](#)...time lines described in charts
- 3) Report... as described in the predefined reports

Bar graph:

Choose the power module and time interval to evaluate - then press show.

The graph will be shown immediately (depending on the size of data it takes some time)



**Module**...the power module to show

**Starttime**...begin of the data window to evaluate


**Endtime**...end of the data window to show

**Show**...refresh the display and take the changes of the parameters

**source**...normally avg. The data which shall be chosen for the evaluation. In a storing interval there are stored avg / min and max values.


**target**...which data of the evaluation period shall be shown: average, minimum or maximum

**log**...if the diagram shall be shown logarithmic or linear



**view**... which data shall be shown: phase voltages U, line voltages ULL or currents

**Abs/rel**...if data shall be shown in absolute values (V, A) or relative (%) to the fundamental





**Type...** whether the harmonics shall be shown (IEC 61000-4-7, the higher frequencies 2-9 kHz in 200 Hz groups or 8-150 kHz in 2 kHz groups)

The amount of data is depending on the real sampling rate and bandwidth of the instrument which has recorded the data. Also the options must have been set up on the [FFT Setup](#) section)

**Limit...** the limit to be shown (IEC 61000-2-4, EN 50160)

**UpTo...** the upper value of FFT to be shown


To **download** data choose the symbol on top right of the chart



Geben Sie hier den Text ein.

### 4.4.1 FFT with Limits

To show also limits on the FFT page select **limit**




In addition the red step chart is shown which indicates the limits of the selected standard.

The values can be:

Class 1,2 or 3 from IEC 61000-2-4

EN 50160



Further limit analysis can be made with the FFT report described in the reports section.

## 4.5 Transients

This page shows a list of transients that have been recorded.  
The captured data are according to the settings in the [transients setup](#).

The number in the menu indicates the amount of recorded transients.

Measurementtitle: wpt

Module: House View: [ ] Edit Transient view: Hidden Small Full Export to CSV

Start	Phase	Alarmtype	Pretime [ms]	Posttime [ms]	Storage Type
15.04.2016, 05:39:31	U_L1	USTAR	1000	3051	ST_BOTH
12.04.2016, 05:36:02	U_L1	USTAR	1000	3071	ST_BOTH
09.04.2016, 05:52:52	U_L1	USTAR	1000	3050	ST_BOTH
29.03.2016, 06:27:18	U_L1	USTAR	1000	3071	ST_BOTH
29.03.2016, 06:17:46	U_L1	USTAR	1000	3061	ST_BOTH

10 25 50 100

Click on the date/time of a transient to get the [data view](#).

### 4.5.1 Transients View

The transient view window has three different ways of viewing the data:


**Hidden**...only the list of transients is shown

**Small**...shows the list and the data


**Full**...shows only the data

Small view:





Full view:



Hidden view:

Start	Phase	Alarmtype	Pretime [ms]	Posttime [ms]	Storage Type
15.04.2016, 05:39:31	U_L1	USTAR	1000	3051	ST_BOTH
12.04.2016, 05:36:02	U_L1	USTAR	1000	3071	ST_BOTH
09.04.2016, 05:52:52	U_L1	USTAR	1000	3050	ST_BOTH
29.03.2016, 06:27:18	U_L1	USTAR	1000	3071	ST_BOTH
29.03.2016, 06:17:46	U_L1	USTAR	1000	3061	ST_BOTH

**Module**...the module of which the transients shall be shown

**View**...the predefined view setup, can be [created or modified](#) by user.

**Export to csv**...direct csv export



...export to other file formats

**Zoom**...with mouse click/hold and zoom in the time window

Click **reset zoom** to go back to full time.

**Tooltip**...to show values on the mouse cursor

**Channel names**...Click into the legend to show/hide any channel.

**Cursor 1 (2)**...to set 2 different cursors. Values and difference will be shown on the screen.

## 4.5.2 Changing the Transient View

To change a transient view is similar to the graph view.

For detailed information please see the chapter [charts/changing the graph](#).

!! Take care that the **"Transient view"** is set !!

Download Upload Delete

---

**TransientView**

**align** Center **Vertical Align** Bottom

**X axis Grid Line width** **Chart height**

The channels type must be set to "raw"

## 4.6 Events

This page shows a list of events that were recorded.

The definition of events corresponds to EN 50160 and evaluated on basis of the voltage band triggers.

The number in the menu indicates the amount of recorded events.

A more complete evaluation of the data can be carried out with the Events Report in the report section.

ARTEMES Analyze New Transients Info Charts FFT Transients 5 Events 5 Alarms 5 Reports Help

Measurementtitle: wpt

Module House Export to CSV

Start	Duration	Restvoltage [%]	Restvoltage [V]	dc	Nominal Voltage	Alarmtype	Phase
15.04.2016, 05:39:31	00:00:00.050	89.71	206.33	0	230.00	USTAR	U_L1
12.04.2016, 05:36:02	00:00:00.070	77.53	178.32	0	230.00	USTAR	U_L2
09.04.2016, 05:52:52	00:00:00.050	86.74	199.50	0	230.00	USTAR	U_L2
29.03.2016, 06:27:18	00:00:00.070	79.07	181.87	0	230.00	USTAR	U_L2
29.03.2016, 06:17:46	00:00:00.060	85.59	196.87	0	230.00	USTAR	U_L1

10 25 50 100

## 4.7 Alarms

This page shows a list of alarms that happened during the recording. The number in the menu indicates the amount of recorded alarms.

Measurementtitle: wpt

Module: House Export to CSV

Start	End	Duration	Alarmtype	Phase
15.04.2016, 05:39:31	15.04.2016, 05:39:31	00:00:00.050	USTAR	U_L1
12.04.2016, 05:36:02	12.04.2016, 05:36:02	00:00:00.070	USTAR	U_L2
09.04.2016, 05:52:52	09.04.2016, 05:52:52	00:00:00.050	USTAR	U_L3
29.03.2016, 06:27:18	29.03.2016, 06:27:18	00:00:00.070	USTAR	U_L2
29.03.2016, 06:17:46	29.03.2016, 06:17:46	00:00:00.060	USTAR	U_L1

10 25 50 100

## 4.8 Reports

In this section predefined reports can be loaded very easy. Reports are scripts that run on the server and are well-laid-out pdf-files.

Chooses the **duration** of the reporting interval (**Start, End**), the **module** and which **report** you want to show - the click "**calc report**".

Start: 13.04.2016 09:41 📅 End: 15.04.2016 09:41 📅 Module: House ⌵ Report: ⌵ Calc Report

Measurementtitle : wpt

Instrument Name	Hausdemo
Location	
Comment	
Instrument Serial	15500188
Starttime	17.03.2016, 19:20:07
Endtime	15.04.2016, 09:41:11
Samplerate	10,000 [Hz]

Modules

House	V / 3 Phase Star
Heating System	V / 3 Phase Star
PV	V / Single Phase
Wind	V / Single Phase

After starting the report there will pop up additional windows, which already depends on the kind of report itself.

The pdf-report will be opened as a new TAB in the browser.

If an error occurs during calculation a text window in the browser will inform you about that. For

analysis of the error please send us the text and provide the data (Mail: support(at)artemes.org). Also if you want to include own reports or modify the existing ones please contact us.

More detailed examples can be found in the [step by step](#) chapter:

[EN50160](#): Power Quality

IEC 61000-2-4: Harmonics and Limits

Events: Dis Dip, ITIC/CBEMA and more

IEC 61400-12-1: Power performance Test

IEC 61400-21: Power Quality Test on renewable energy sources

Energyreport: for ISO 50001 reports

## 5 The Server Solution

ARTEMES provides the data analysis functions also as a dedicated server.

All data can be synchronised during the running measurement to the server from several instruments at the same time.

The evaluation of data can then be done crosswise between different data sources. the strong [reporting engine](#) is used.

## 6 Report Engine

The report engine is a very strong and flexible engine which consists of two parts:

- 1) The report calculation - This part is based on Matlab(r) / Octave.
- 2) The layout engine - This engine is based on Latex.

The reports can be loaded directly from command line, the editor or from the web software in [post processing mode](#).

There are a large number of already [predefined reports](#) available.

We provide a [set of functions](#) with which you get direct access to the data.

### 6.1 Predifined Reports

Diagrams:	
U_I_Diagram	Voltage and Current

U_I_f Diagra m	Voltage, current and frequency
P_Q_S _PF_D iagram	All kinds of Power, total values
U_min _max_ Diagra m	min and max of voltage

Reports according to  
certain Standards:

<a href="#">En 50160</a>	Power Quality Report according to EN 50160
IEC 61000- 2-4	Power Quality Report for customer grids according to IEC 61000-2-4
IEC 61400- 12-1	Power Performance Test for Wind turbines according to IEC 61400-12-1
IEC 61400- 21	Power Quality Type Test for Wind turbines and other renewables according to IEC 61400-21
DisDip	Event List, Cbema curve and dis dip statsitic
Transie nt List	List of recorded faults
Energy Report	Energy Report for ISO 50001

this lists may vary from the  
real installed diagrams

## 7 Matlab(TM) routines to load Data

ARTEMES provides a set of functions to get direct access to the data in Matlab(r) or Octave.

First we should explain the data structure:

There are some different kinds of data in the ARTEMES data system:

- recorded data - this are data which have been periodically stored, but not in full sample mode. for example 1 min average values of power, 10 second values of frequency or 10 minute rms values of voltages. The data are stored in the directory M\_xxxx/P\_xxx/D\_xxx/async/\*.001. To load those data see "[Loading recorded data](#)"
- triggered data (Transients): this data are data stored with full samples (for example 10Samples/sec, 2MSamples/sec). They have been triggered automatically on a predefined event and have a pre and post storing time. The data are stored in the directory M\_xxxx/P\_xxx/Transients/\*.ams. To load those data see "[Loading triggered data](#)"
- streamed data: this data have been recorded with full samples continuously. The data are stored in the directory M\_xxxx/sync/\*.ams. To load those data see "[Loading streamed data](#)"

Further functions to use in Matlab(TM) are:

- To get the channel index number:
- Change time intervals: To normalize to a new [time axis](#)
- Event List: to load the [event list](#)

### 7.1 Loading recorded data (reduced storing)

Recorded data are data which have been periodically stored, but not in full sample mode. for example 1 min average values of power, 10 second values of frequency or 10 minute rms values of voltages. The data are stored in the directory M\_xxxx/P\_xxx/D\_xxx/async/\*.001.

**getAsyncSingleValueFromFilter...** returns a vector where the first column is time, the second is the value

function [retval] = getAsyncSingleValueFromFilter(abasedir, atitle, alocation, acomment, apowermodulename, achannelcode, astarttime, aendtime, avaluetype)

abasedir...the directory where the function starts searching (Datapath)

atitle...filter for the title of the measurement (if empty, then all values are taken, where the other filter values are used)

alocation...filter for the allocation of the measurement (if empty, then all values are taken, where the other filter values are used)

acomment...filter for the comment of the measurement (if empty, then all values are taken, where the other filter values are used)

apowermodulename...filter for the powermodule of the measurement (if empty, then all values are taken, where the other filter values are used)

achannelcode...the number of the channel from the [converNameToLogCode](#) function

astarttime...starttime of the data to be loaded. if 0 then the first valid data is taken

aendtime...stoptime of the data to be loaded. if 0 then the last valid data is taken

avaluetype... 1=max, 2=min, 3=average, 4=S (deviation) or for counters 4=difference to last value

**getArrayValueFromFilter**...returns an array value like harmonics, where the first column is time, the others the harmonics

```
function [retval] = getArrayValueFromFilter (abasedir, atitle, alocation, acomment,
apowermodulename, achannelcode, astarttime, aendtime, avaluetype)
```

## 7.2 Loading triggered data (full sample storing)

Triggered data (or "Transients") are data stored with full samples (for example 10Samples/sec, 2MSamples/sec). They have been triggered automatically on a predefined event and have a pre and post storing time.

To load the data you use the same function as for [streamed data](#), but the data path is different and the name of transient is depending on which transient you want to load.

## 7.3 Loading streamed data (full continuous sample storing)

Streamed data have been recorded with full samples continuously.

To load the data use "getTransient"

```
function [ output_args , firsttime_out, x_axis_out] = getTransient(afile, achannelindex,
astartoffset, amaxsize)
```

Parameters:

afile ... the direct path and name of the file: e.g "yourroot/M\_xxxx.../sync/?????????.ams"  
this data have been recorded with full samples continuously. It has the extension ".ams"

achannelindex ... the index of the channel to load from the file (starts with 1). Example: If you want to load voltage 2 and the file has three voltages in rising order, then use "2"

astartoffset ... number of samples to cut before the loaded data.

amaxsize ... maximum number of samples to load

Returns

Output\_args ... The function returns the raw data in an array consisting of timestamp and data.

Firsttime\_out ... time stamp of first value

X\_axis\_out: time axis in absolute time

Example:

```
m = 'M_xxx';
basedir = ['/Users/dg/Documents/Messung xxx/AM5/' m];
p1 = [basedir '/sync/0000.ams'];
```

```
% Load Setup info with channel infos k = channel index for getTransient
%
```



```
inf = [basedir '/' m '.amc'];
info = loadjson(inf);

k=0;
for i=1:size(info.inputs(1).analog(1).channels,2)
    if (info.inputs(1).analog(1).channels{i}.save)
        i
        k = k+1
        channel = info.inputs(1).analog(1).channels{i}.caption
    end
end

%% Shows titel of measurement
tit = [basedir '/' m '.amm'];
titel = loadjson(tit)

[y1, dt1, x1] = getTransient(p1,12,20000*23,20000*4);
plot(x1(:,1),y1(:,1));
```

## 7.4 Get the Channel Index

**convertNameToLogCode**...returns the channel code from the name of the parameter. The channel code and the parameter are defined in the [channel list file](#).

```
name=convertNameToLogCode(achannelfile,channelname)
```

achannelfile...the channel list file, full path and name

channelname...name of the parameter (for exmaple "P, U\_rms\_1")

name...the value of the channel

## 7.5 To normalice to a new time axis

**normToTime**...returns a vector with normalized time intervals

```
values=normToTime(values,starttime,endtime, averagetime, avaluetype);
```

averagetime...the new time interval

## 7.6 Loading the Event List

`getEventsFromTitle`...loads the list of events from a power module

```
function [retval] = getEventsFromTitle (abasedir, atitle, astarttime, aendtime)
```

# 8 Installation and System Setup

## 8.1 System Setup of measurement instrument

Pressing the setup button on top right of the browser you come into the system setup mode.



**ID**...identifier of the instrument

**System Name**...name of the instrument how it appears on the server

**Sync**...activate/deactivate the synchronisation of the data to the server

**Current Network**...used network

## 8.2 Installing the Measurement instrument


Geben Sie hier den Text ein.

## 8.3 Installing the Web Server

Installation of the AM power server

1. Download the file `artemes.zip` from <https://www4.artemes.org/d/64438af2bd/>
2. Unzip the file to `c:\artemes`

The following file structure will be created:



### 3. Modify the users.json in c:\artemes\config (Details from users.json in ...)

In the section groups/devices for all users who shall see the instrument, the number 90 must be entered at the end.



```

...
{
  "version": "1.0.0",
  "groups": [{
    "id": "2CC15FBC-8426-43AA-8400-BC965899F420",
    "name": "Admin",
    "right": 15,
    "devices": [...,90]
  },
  {
    "id": "12345678-1234-5678-9012-ABCDEF012350",
    "name": "viewer",
    "right": 1,
    "devices": [...,90]
  }
],
...

```

### 4. Register the system service

In C:\artemes\bin there is the file runassvc.exe  
Click with the right mouse button, open as administrator.  
Then enter the following:



Click OK.

The service is created and the it should be set to "automatic".

#### 5. Setting the paths for the reporting.

After that you go to system control - advanced system configuration - environment variable - system variable and add the paths to the folder path.txt. This ensures the routing to the required programmes in order to calculate the data.

```
C:\Program Files\OpenVPN\bin;C:\Program Files\NTP\bin;C:\artemes\Octave\Octave-3.8.1\bin;C:\artemes\Octave\gnuplot\bin;C:\artemes\Octave\texlive\2014\bin\win32;C:\artemes\gs9.14\bin
```

#### 6. Setting the path for the measured data

This is done in the file serverconfig.jsonim verzeichnis c:\artemes\config

```
{  
  "version": "1.0.0",  
  "measurementpath": "C:\\artemes\\devices\\"  
}
```



The path is listed here so that the GUI knows where the measured data are stored. (In this case I chose C:\\artemes\\devices\\.)

**Attention:** Please consider the double-backslash!


#### 7. For the operation of the web server the IIS or Apache is needed.

It is assumed that the ISS is used as this one is enclosed in Windows and as it can easily be installed directly via Windows afterwards.

Under administration - internet information services the root directory of IIS has to be put to c:\artemes\www. (Systemsteuerung - alle Systemsteuerungselemente - Verwaltung - Internetinformationsdienste)



When going to Sites-default sites there is a link bottom down on the right (general settings - Grundeinstellungen). Please, list the path here.



8.) Start service 4.

9.) Test the installation with the browser.

Remark:

The following TCP ports are necessary:

Port 80           Http

Port 2001        exchange of data streaming between browser and AM server.

## 8.4 Channel List File

This file describes all variables used inside the software and can be adopted to your needs.

Name of the file: channellist.json

Location: config directory of the instrument or server.

It is based on a json structure.

Each variable has an unique identifier.

Example for Frequency, Id=1 and unit=Hz:

```
"id": 1,  
"name": "Frequency",  
"unit": "Hz",
```

```
"color": 0,  
"array": false,  
"group": 1
```

Array channels are for example used for harmonics where more columns are stored under one name.

Example: voltage Harmonics for voltage U\_L1

```
"id": 23,  
"name": "U_L1_H",  
"unit": "V",  
"color": 0,  
"array": true,  
"group": 1
```

## 9 Step by Step Tutorial

The step-by-step guide is always described in a few steps to get the report or result you want.

[Power Measurement with different connections](#)

[EN50160](#): Power Quality

### 9.1 Power Measurement

Depending on what shall be measured there are different ways to connect the instrument.

In general the [star connection](#) shall be used for multi phase systems.

If there is no neutral, then the [delta connection](#) OR the [star connection](#) can be used. In the second case just make an artificial star point by connection the negative inputs from the voltage channels together. This is used typically by measuring on electrical engines.

In [medium voltage grids](#) star is used as well as delta. The VTs are normally connected in star. Measuring in parallel lets you see the earth faults (phase voltage). Measuring the Line voltages shows the voltage on the customer side itself (delta to star conversion). To see both just measure star and use the "calculate ULL" option in the power module connection setup.

#### 9.1.1 Low Voltage Grid


Measurements in low voltage grids are typically used to measure power and power quality in a distribution grid.

The connection there is normally star and in addition also the neutral voltage (U<sub>N</sub>, neutral to earth), the neutral current (I<sub>N</sub>) and the earth current (I<sub>PE</sub>) are for interest.

1): connect the channels to your instrument



Example: AM-10-PA2



2) Connect to your instrument using a web browser, go to set up mode and set all input channels and transducers

3) Set the grid type to star and assign the input channels

ARTEMES Setups AI Power Extra modules Storage Analyze ✓ ▶ ⦿

module Add Powermodule

General Choose a grid type FFT Mathe channels Trigger

**Choose a grid type**

3 Phase Star

Calc. ULL  
 Calc. third current  
 I N

Calc Currents  
 U N  
 I PE

**U L1**  
 ai0

**U L2**  
 ai1

**U L3**  
 ai2

**I L1**  
 ai4

**I L2**  
 ai5

**I L3**  
 ai6

4) If neutral and earth are connected as well then check the boxes and assign also this channels

5) Start the measurement and see the power values for the star connection.

Caption	Phase 1	Phase 2	Phase 3
U RMS LE	229.655 [V]	227.961 [V]	228.793 [V]
Phi I	44.11 °	40.14 °	23.82 °
Phi U	0.00 °	119.72 °	-120.04 °
I RMS LE	2.577 A	0.530 A	0.931 A
P	371.419 W	89.810 W	176.602 W
Q	369.298 Var	75.149 Var	80.856 Var
S	530.280 VA	117.655 VA	196.601 VA
PF	0.700	0.763	0.898
PST LE	0.299	0.234	0.467
PLT LE	0.668	0.576	0.698
U THD LE	2.642 %	2.211 %	2.530 %

### 9.1.2 Medium and High Voltage Grid


Measurements in medium and high voltage grids are typically used to measure power and power quality in medium voltage distribution or high voltage transmission grids.

The connection there is normally star on VTs. Interesting are Phase voltages and Line voltages. By using the checkbox "Calc. ULL" both can be measured at the same time.

1) connect the channels to your instrument on the secondary side of VTs and CTs

Example: AM-10-PA2

The secondary side of CTs can be measured directly with the 5A inputs (Screw terminals) or by using the AM-CL5 Clamp.



2) Connect to your instrument using a web browser, go to set up mode and set all input channels and transducers. Take care of the transducer ratios (prim/sec).

3) Set the grid type to star and assign the input channels. Check the box "Calc U LL" on the left top side.

4) Start the measurement and see the power values for the combined star/delta connection. The voltage values on the right side are now for star (U RMS LE) and delta (U RMS LL)

Frequency	50.027 [Hz]
P Total	28.117 KW
Q Total	18.039 KVA
S Total	35.115 KVA
PF	0.881
Unbalance U	142.357 m%
Unbalance I	64.746 %

H1	U	I	phi U	phi I	Cos phi
1	11878.90	2.08	0.00	-26.49	0.90
2	11815.31	0.21	-119.65	-87.05	0.05
3	11764.38	0.65	120.12	-33.35	0.64

Caption	Phase 1	Phase 2	Phase 3	N
U RMS LE	11.880 K[V]	11.817 K[V]	11.757 K[V]	0.691 m[V]
U RMS LL	20.484 K[V]	20.439 K[V]	20.483 K[V]	
Phi U	-26.49 °	-87.05 °	-33.35 °	
Phi I	0.00 °	-119.65 °	120.12 °	
I RMS LE	2.549 A	2.087 A	1.273 A	1.927 A
Energy	NaN Wh	NaN Wh	NaN Wh	
P	21.957 KW	59.856 W	6.100 KW	I PE
Q	11.275 KVA	2.530 KVA	4.235 KVA	24.254 mA
S	24.935 KVA	2.608 KVA	7.572 KVA	
PF	0.881	22.949 m	0.806	
PST LL	NaN	NaN	NaN	
PLT LL	NaN	NaN	NaN	
U THD LE	2.302 %	1.889 %	2.045 %	210.524 %
U THD LL	1.959 %	1.946 %	2.032 %	210.524 %

5) HINT: If you want to use the connection also for fault recording set the nominal value to the nominal U LL value - then the limits will be used relative to U LL!


### 9.1.3 Low Voltage Delta (Motor)

To measure the power of an electrical engine (motor) [star](#) or delta-connection can be used.

In this example the engine is connected in delta

1) connect the channels to your instrument

Example: AM-10-PA2



2) Connect to your instrument using a web browser, go to set up mode and set all input channels and transducers

3) set the grid type to delta and assign the input channels

The screenshot displays the ARTEMES software interface for configuring a power measurement setup. The 'Choose a grid type' section is active, showing a dropdown menu set to '3 Phase Delta'. Below this, there are several checkboxes: 'Calc. third current', 'I N', 'Calc Currents' (checked), 'U N', and 'I PE'. The 'Calc Currents' checkbox is checked. The interface also shows three rows of input fields for voltage (U) and current (I) measurements: U L12 (ai0), U L23 (ai1), U L31 (ai2) and I L1 (ai4), I L2 (ai5), I L3 (ai6). A schematic diagram at the bottom illustrates a three-phase delta connection with lines U1, U2, U3 and current measurements I1, I2, I3.


4) Start the measurement and see the power values for the delta connection.

#### 9.1.4 Low Voltage Star with artificial Star point (Motor)

To measure the power of an electrical engine (motor) star or [delta-connection](#) can be used.

In this example the engine is connected in star with an artificial star point.

1): connect the channels to your instrument  
Example: AM-10-PA2



2) Connect to your instrument using a web browser, go to set up mode and set all input channels and transducers

3) set the grid type to star and assign the input channels



The screenshot shows the ARTEMES software interface. The top navigation bar includes 'Setups', 'AI', 'Power', 'Extra modules', 'Storage', and 'Analyze'. The 'Power' module is selected. Below the navigation bar, there are tabs for 'General', 'Choose a grid type', 'FFT', 'Mathe channels', and 'Trigger'. The 'Choose a grid type' tab is active, showing a dropdown menu set to '3 Phase Star'. Below this, there are checkboxes for 'Calc. ULL', 'Calc. third current', and 'I N' (all unchecked), and 'Calc Currents', 'U N', and 'I PE' (all checked). The interface also displays six input fields for voltage (U L1, U L2, U L3) and current (I L1, I L2, I L3) measurements, each with a color-coded dropdown menu and a corresponding color swatch. At the bottom, there are two diagrams: a 3-phase star connection diagram with phases U1 (red), U2 (blue), and U3 (green), and a neutral point diagram labeled 'N'.

4) Start the measurement and see the power values for the star connection.

## 9.2 Report: EN50160

To create an EN50160 measurement and get the report you have to do mainly 2 steps:

- 1) Measurement
- 2) Report

To perform this example you should have already some knowledge of [setting up](#) an instrument and how to [evaluate data](#).

The report can be created already during the running measurement. It is not necessary to stop the recording during data processing.

#### 1) Measurement set up

After configuring the [AI channels](#) create a new [power module](#).

The following settings must be done for EN50160 (3 phase star or delta)

Nominal Voltage UL (or ULL for delta)

Nominal frequency

Save interval to 600 sec

Save Interval Frequency to 10 sec

Save period values

Symetric components: Basic calculation

**Name**

**Description**

<b>Nominal Voltage LE [V]</b>	<b>Nominal Frequency [Hz]</b>	<b>Frequency source</b>
<input type="text" value="230"/>	<input type="text" value="50"/>	<input type="text" value="Voltage"/>
<b>Save Interval (sec)</b>	<b>Save Interval Freq. (sec)</b>	<b>Samplerate Divider</b>
<input type="text" value="600"/>	<input type="text" value="10"/>	<input type="text" value="1"/>
<b>Periodcount</b>	<b>Periodduration</b>	<b>Overlap Factor [%]</b>
<input type="text" value="10"/>	<input type="text" value="1"/>	<input type="text" value="50"/>

Save Periodvalues

**Symetric Components**

Basic Calculation       Enhanced Calculation

FFT settings:

THD with 40 lines

FFT count to minimum 25  
sidebands count to 1  
UL active for star  
ULL active for delta

Example star:

FFT

---

<b>FFT Count</b>	<b>Sidebands Count</b>	<b>Interharm. Sidebands Count</b>
<input type="text" value="25"/>	<input type="text" value="1"/>	<input type="text" value="3"/>

THD

UL

<input type="checkbox"/> I	<input type="checkbox"/> P
<input type="checkbox"/> Q	<input type="checkbox"/> cos Phi
<input type="checkbox"/> Phi U	<input type="checkbox"/> Phi I
<input type="checkbox"/> Interharmonics	<input type="checkbox"/> Calc. Higher Harmonics
<input type="checkbox"/> Calc. Highest Harmonics	<input type="checkbox"/> Smoothing Filter

example Delta:

FFT

---

<p><b>FFT Count</b></p> <input style="width: 100%;" type="text" value="25"/>	<p><b>Sidebands Count</b></p> <input style="width: 100%;" type="text" value="1"/>	<p><b>Interharm. Sidebands Count</b></p> <input style="width: 100%;" type="text" value="3"/>
--	---	--

THD

<input type="checkbox"/> UL	<input checked="" type="checkbox"/> ULL
<input type="checkbox"/> I	<input type="checkbox"/> P
<input type="checkbox"/> Q	<input type="checkbox"/> cos Phi
<input type="checkbox"/> Phi U	<input type="checkbox"/> Phi I
<input type="checkbox"/> Interharmonics	<input type="checkbox"/> Calc. Higher Harmonics
<input type="checkbox"/> Calc. Highest Harmonics	<input type="checkbox"/> Smoothing Filter

Flicker settings:

PST (min) to 10 minutes

PLT to 12 counts

Flickerfilter to Auto

both Overlap values to 0%

Flicker  Save Current Flicker

---

<p><b>PST (min)</b></p> <input style="width: 100%;" type="text" value="1"/>	<p><b>PLT (PST count)</b></p> <input style="width: 100%;" type="text" value="12"/>	<p><b>Flickerfilter (Hz)</b></p> <input style="width: 100%;" type="text" value="Auto"/>
<p><b>PST Overlap [%]</b></p> <input style="width: 100%;" type="text" value="0"/>	<p><b>PLT Overlap (%)</b></p> <input style="width: 100%;" type="text" value="0"/>	

Trigger

Max. Storage Time [ms]   Separate Phases

Voltageband Star[%]

Max.	<input type="text" value="110"/>	Max.	<input type="text" value="108"/>	Pretime [ms]	<input type="text" value="1000"/>	Holdofftime [ms]	<input type="text" value="0"/>	Flagging	<input checked="" type="checkbox"/>	Relative	<input checked="" type="checkbox"/>
Min.	<input type="text" value="90"/>	Min.	<input type="text" value="92"/>	Type	<input type="text" value="Both"/>	Posttime [ms]	<input type="text" value="3000"/>	Posttime ext.	<input type="checkbox"/>		

Transient recorder settings:

activate band trigger for star or delta

start: 90% to 110%

stop: 92% to 108%

activate flagging

activate relative to have percentage limits of nominal voltage

Trigger

Max. Storage Time [ms]   Separate Phases

Voltageband Star[%]

Voltageband Delta[%]

Max.	<input type="text" value="110"/>	Max.	<input type="text" value="108"/>	Pretime [ms]	<input type="text" value="1000"/>	Holdofftime [ms]	<input type="text" value="0"/>	Flagging	<input checked="" type="checkbox"/>	Relative	<input checked="" type="checkbox"/>
Min.	<input type="text" value="90"/>	Min.	<input type="text" value="92"/>	Type	<input type="text" value="Both"/>	Posttime [ms]	<input type="text" value="3000"/>	Posttime ext.	<input type="checkbox"/>		

Then start the measurement and [record the data](#) for a minimum of one week

2) Report

Star the [Analyze](#) section and open the [reports](#) page in the menu bar.

The choose the time, the power module and the EN50160 as shown below:

ARTEMES Analyze Info Charts FFT Transients 2 Events 2 Alarms 2 Reports 0 Help

Start: 27.05.2016 20:06 End: 03.06.2016 18:29 Module: House Report: EN50160 Calc Report

Measurementtitle : Haus

Instrument Name	Hausdemo
Location	Graz
Comment	
Instrument Serial	15500188
Starttime	27.05.2016, 20:06:38
Endtime	03.06.2016, 18:29:31
Samplerate	10,000 [Hz]

Modules

House	V / 3 Phase Star
Heating System	V / 3 Phase Star
PV	V / Single Phase
Wind	V / Single Phase

52.0 GB 35 % available disk space GPS off A product of ARTEMES GmbH 2016. All rights reserved.

Next step is to fill in the report specific data:


**Class**...the voltage level of the measurement (influences the limits in the evaluation according to the standard)

**Iland**...grid connected or ilanfd grid (influences the limits in the evaluation according to the standard)

**Phase or line values**...to switch between UL and ULL

**Author**...your name

**Company**...Cour Company



Data for EN50160

Class	Low voltage
Iland	grid connected
Phase Values	Phase values
Author	Demouser
Company	ARTEMES


Start Cancel

After clicking on Start the Report will get calculated and is shown on the screen as PDF file. Depending on the network connection this can take some minutes.

Example pages from the EN50160 report:

l...lower limit  
1...first limit  
2...second limit

## 2.2 PQ data and Limits - Bar



Report generated by ARTEMES Software - [www.artemes.org](http://www.artemes.org)

Page 4 of 11

EN50160:2011, LV



## 2.3 Table of PQ data

Name	Unit	Quantil	Value	Limit	Valid
U L1	V	5.0	220.99	>= 207.00	YES
U L1	V	95.0	228.05	<= 253.00	YES
U L1	V	0.0	215.39	>= 195.50	YES
U L1	V	100.0	230.27	<= 253.00	YES
U L2	V	5.0	222.78	>= 207.00	YES
U L2	V	95.0	231.43	<= 253.00	YES
U L2	V	0.0	220.50	>= 195.50	YES

# Index

## - 3 -

3 Phase star 18

## - 4 -

4 wire 18

## - 5 -

5 wire 18

## - A -

ARON 24

## - C -

Counter 9

## - D -

DFR 27

Disturbance Fault Recorder 27

## - E -

Extra Module 37

## - F -

Fault Recorder 27

Fault Recording 13

Frequency Analysis 13

## - P -

PFR 27

Phasor Measurement 13

Power Fault Recorder 27

Power Measurement 13

Power Module 13

Power Quality 13

## - S -

system setup 78

## - T -

TEDS 9

## - V -

V-connection 24

Virtual Power Meter 13